

Instructions for Bluetooth thermostat

First Step Activate Bluetooth on your phone.

1. Launch the "University of Leeds App" application on your phone it is called University of Leeds Heating App and can be found in Google Play and App Store. Or scan the QR codes:



2. Once the app on your phone has been downloaded open the app.
3. You will see the screen that says: **push to heat**.
4. Swipe to the right until you see a screen that says: **push to pair**. **1**
5. Tap the **push to pair** button.

6. The camera on your phone will now launch.
7. Scan the QR code on the side of the radiator – the screen should now jump back to push to pair.
8. Swipe to the temperature screen to set your desired heat. This will stay at this temperature unless you go back to the screen to change it. **2**
9. Swipe back to the **push to heat** screen and tap the button. **3**
10. The radiator will now come on for a 2-hour period.
11. If you require further heat after the 2 hours just tap the **push to heat** screen and another 2 hours of heat will be activated. **3**
12. When you leave your accommodation the Bluetooth thermostat will disconnect automatically and will connect again when you enter your accommodation.

NOTE

If you manually turn off Bluetooth on your device, in order to reconnect to the thermostat, you will have to turn Bluetooth back on and restart your phone. This will allow you to relaunch the app and begin the process again.

In communal areas there is no Bluetooth present, to operate the radiator just select the temperature required and press the centre button. The radiator will now come on for 2 hours. If more heat is required then repeat the process.

Your radiator is pre-programmed to come on in the morning between 06:00 hrs and 08:00 hrs, and between 17:00hrs and 19:00hrs in the evening.

If Bluetooth device is present it will come on at 17c
If Bluetooth device is not present it will come on at 10c

